

Perdüre AU52

application instructions



Apply Perdüre AU52 over properly prepared surfaces. Surfaces must be free from oils, grease, water or other foreign matter. Surface should be dry and above 50°F and rising. Relative humidity should not exceed 85%. Perdüre AU52 is moisture sensitive during application and initial cure. Do not apply if surface temperature is within 5°F of Dew Point. Not recommended on floors susceptible to hydrostatic pressure. Best methods of application are using a shed resistant phenolic core mohair cover. Roll in the same direction, always keeping a wet edge. Do not over roll the product. For safety and proper curing, proper ventilation is necessary throughout application and cure. When using pigmented intermediate coats, be sure the batch numbers are all the same to provide a uniform base color. Perdüre AU52 can be sprayed with an airless or conventional unit.

